

Hardware Included:

Tools Required:

• 5/32 Allen Wrench



Step 1:

Place the seat upside down on a clean, padded surface.

Step 2:

Center leg assembly on underside of top and attach using 1/4-20 x 3/4" BH Bolt (do not over tighten).

Note: Rocky Bench over 60" long has third leg.